



Ripstaal reveal installation instructions.

1. Cut the window reveal to the desired width and length. Cut the U-profiles to the desired lengths.



2. Install the U-profile to the joinery. The U-profile has got a strong adhesive strip. This adhesive strip makes it easy to attach the U profile to the joinery. Before you stick the U-profile to the joinery put a pencil line on the joinery using a level. Remove the tape and stick the U-profile to the joinery.



- Slide the reveal into the U-profile and cover the back of the reveal with a non-expandable building foam/adhesive. Check the reveal with a builder's square and level to ensure the reveal is sitting nice and strait. It is important to use non-expandable foam to make sure the reveal doesn't move after installation.



- When all the reveals are installed (left, right, top and bottom) and the expandable foam has set, finish the joints with a paintable sealant/no more gab. Don't apply sealant/no more gab on the U-profile flange.

