



RIPSTAAL KLICK-BOARD®

THE RIGHT SHAPE IN ONE CLICK
WITH OUR INNOVATIVE DRYWALL

7 simple steps

Attach battens in order to secure the Klick-board.

1

Cut the Klick-board to size horizontally according to the desired dimensions.

2

Remove the lock strip from the Klick profile.

3

Click the board into the desired corner, column or housing from the outer edges.

4

Carefully press along the sides of the Klick profile in order to ensure that the profile has properly clicked into place everywhere.

5

Attach the Klick-board to the battens using screws and finish the seams with mesh tape.

6

The Klick-board can be finished using most any decorative material.
Read the requirements for use of the products in question for possible primers.

7